


TEMPERATURE-TABLE for PTCR

Higher quality products and lower costs through improved, reliable firing control

Type PTCR - HTH		Ring Colour : White
Vibrantz no. : 1400610		Dimensions : ± 20 x 10 x 7,0 mm
Temperature Range °C : 1450 - 1750°C		

Ring dia- meter mm	Ring tempe- rature °C	Ring dia- meter mm	Ring tempe- rature °C	Ring dia- meter mm	Ring tempe- rature °C	Ring dia- meter mm	Ring tempe- rature °C	Ring dia- meter mm	Ring tempe- rature °C	Ring dia- meter mm	Ring tempe- rature °C
		19,69	1450	19,19	1561	18,69	1637	18,19	1677	17,69	1715
		19,68	1452	19,18	1563	18,68	1638	18,18	1678	17,68	1716
		19,67	1454	19,17	1564	18,67	1639	18,17	1679	17,67	1717
		19,66	1457	19,16	1566	18,66	1640	18,16	1679	17,66	1718
		19,65	1459	19,15	1568	18,65	1641	18,15	1680	17,65	1719
		19,64	1461	19,14	1570	18,64	1642	18,14	1681	17,64	1720
		19,63	1464	19,13	1572	18,63	1643	18,13	1681	17,63	1721
		19,62	1466	19,12	1574	18,62	1644	18,12	1682	17,62	1722
		19,61	1468	19,11	1576	18,61	1645	18,11	1683	17,61	1723
		19,60	1471	19,10	1577	18,60	1646	18,10	1683	17,60	1724
		19,59	1473	19,09	1579	18,59	1647	18,09	1684	17,59	1725
		19,58	1475	19,08	1581	18,58	1648	18,08	1685	17,58	1727
		19,57	1478	19,07	1583	18,57	1649	18,07	1685	17,57	1728
		19,56	1480	19,06	1585	18,56	1650	18,06	1686	17,56	1729
		19,55	1482	19,05	1586	18,55	1651	18,05	1687	17,55	1730
		19,54	1485	19,04	1588	18,54	1651	18,04	1687	17,54	1731
		19,53	1487	19,03	1590	18,53	1652	18,03	1688	17,53	1733
		19,52	1489	19,02	1591	18,52	1653	18,02	1689	17,52	1734
		19,51	1492	19,01	1593	18,51	1654	18,01	1689	17,51	1735
		19,50	1494	19,00	1595	18,50	1655	18,00	1690	17,50	1736
		19,49	1496	18,99	1596	18,49	1656	17,99	1691	17,49	1738
		19,48	1498	18,98	1598	18,48	1657	17,98	1691	17,48	1739
		19,47	1501	18,97	1599	18,47	1657	17,97	1692	17,47	1740
		19,46	1503	18,96	1601	18,46	1658	17,96	1693	17,46	1742
		19,45	1505	18,95	1603	18,45	1659	17,95	1693	17,45	1743
		19,44	1508	18,94	1604	18,44	1660	17,94	1694	17,44	1744
		19,43	1510	18,93	1606	18,43	1661	17,93	1695	17,43	1746
		19,42	1512	18,92	1607	18,42	1661	17,92	1696	17,42	1747
		19,41	1514	18,91	1609	18,41	1662	17,91	1696	17,41	1749
		19,40	1516	18,90	1610	18,40	1663	17,90	1697	17,40	1750
		19,39	1519	18,89	1611	18,39	1664	17,89	1698		
		19,38	1521	18,88	1613	18,38	1664	17,88	1699		
		19,37	1523	18,87	1614	18,37	1665	17,87	1699		
		19,36	1525	18,86	1616	18,36	1666	17,86	1700		
		19,35	1527	18,85	1617	18,35	1667	17,85	1701		
		19,34	1530	18,84	1618	18,34	1667	17,84	1702		
		19,33	1532	18,83	1620	18,33	1668	17,83	1702		
		19,32	1534	18,82	1621	18,32	1669	17,82	1703		
		19,31	1536	18,81	1622	18,31	1669	17,81	1704		
		19,30	1538	18,80	1624	18,30	1670	17,80	1705		
		19,29	1540	18,79	1625	18,29	1671	17,79	1706		
		19,28	1542	18,78	1626	18,28	1671	17,78	1707		
		19,27	1544	18,77	1627	18,27	1672	17,77	1707		
		19,26	1547	18,76	1629	18,26	1673	17,76	1708		
		19,25	1549	18,75	1630	18,25	1674	17,75	1709		
		19,24	1551	18,74	1631	18,24	1674	17,74	1710		
		19,23	1553	18,73	1632	18,23	1675	17,73	1711		
		19,22	1555	18,72	1633	18,22	1675	17,72	1712		
		19,21	1557	18,71	1634	18,21	1676	17,71	1713		
		19,20	1559	18,70	1635	18,20	1677	17,70	1714		

Powder Batch # : 460	Batch approved
Date : 02/04/2024	Quality Inspection : 
For inquiries :	
Customer Service Desk	
Phone : +49 69 27116 432	
Fax : +49 69 27116 243	





