

TEMPERATURE-TABLE for PTCR

Higher quality products and lower costs through improved, reliable firing control

Type PTCR - HTH

Vibrantz no. : 1400610

Temperature Range °C : 1450 - 1750°C

Ring Colour : White

Dimensions : ± 20 x 10 x 7,0 mm

Ring dia- meter mm	Ring tempe- rature °C	Ring dia- meter mm	Ring tempe- rature °C	Ring dia- meter mm	Ring tempe- rature °C	Ring dia- meter mm	Ring tempe- rature °C	Ring dia- meter mm	Ring tempe- rature °C	Ring dia- meter mm	Ring tempe- rature °C
		19,70	1448	19,20	1575	18,70	1642	18,20	1681	17,70	1736
		19,69	1451	19,19	1577	18,69	1643	18,19	1681	17,69	1737
		19,68	1454	19,18	1579	18,68	1644	18,18	1682	17,68	1739
		19,67	1457	19,17	1581	18,67	1644	18,17	1683	17,67	1740
		19,66	1460	19,16	1582	18,66	1645	18,16	1684	17,66	1742
		19,65	1463	19,15	1584	18,65	1646	18,15	1685	17,65	1743
		19,64	1466	19,14	1586	18,64	1647	18,14	1686	17,64	1744
		19,63	1469	19,13	1588	18,63	1648	18,13	1687	17,63	1746
		19,62	1472	19,12	1589	18,62	1649	18,12	1688	17,62	1747
		19,61	1474	19,11	1591	18,61	1649	18,11	1689	17,61	1749
		19,60	1477	19,10	1593	18,60	1650	18,10	1689	17,60	1750
		19,59	1480	19,09	1594	18,59	1651	18,09	1690		
		19,58	1483	19,08	1596	18,58	1652	18,08	1691		
		19,57	1486	19,07	1598	18,57	1652	18,07	1692		
		19,56	1489	19,06	1599	18,56	1653	18,06	1693		
		19,55	1491	19,05	1601	18,55	1654	18,05	1694		
		19,54	1494	19,04	1602	18,54	1655	18,04	1695		
		19,53	1497	19,03	1604	18,53	1655	18,03	1696		
		19,52	1500	19,02	1605	18,52	1656	18,02	1697		
		19,51	1502	19,01	1607	18,51	1657	18,01	1698		
		19,50	1505	19,00	1608	18,50	1658	18,00	1699		
		19,49	1508	18,99	1610	18,49	1658	17,99	1700		
		19,48	1510	18,98	1611	18,48	1659	17,98	1702		
		19,47	1513	18,97	1612	18,47	1660	17,97	1703		
		19,46	1516	18,96	1614	18,46	1661	17,96	1704		
		19,45	1518	18,95	1615	18,45	1661	17,95	1705		
		19,44	1521	18,94	1616	18,44	1662	17,94	1706		
		19,43	1523	18,93	1618	18,43	1663	17,93	1707		
		19,42	1526	18,92	1619	18,42	1664	17,92	1708		
		19,41	1528	18,91	1620	18,41	1664	17,91	1709		
		19,40	1531	18,90	1621	18,40	1665	17,90	1711		
		19,39	1533	18,89	1622	18,39	1666	17,89	1712		
		19,38	1536	18,88	1624	18,38	1666	17,88	1713		
		19,37	1538	18,87	1625	18,37	1667	17,87	1714		
		19,36	1541	18,86	1626	18,36	1668	17,86	1715		
		19,35	1543	18,85	1627	18,35	1669	17,85	1717		
		19,34	1545	18,84	1628	18,34	1669	17,84	1718		
		19,33	1547	18,83	1629	18,33	1670	17,83	1719		
		19,32	1550	18,82	1630	18,32	1671	17,82	1720		
		19,31	1552	18,81	1631	18,31	1672	17,81	1722		
		19,30	1554	18,80	1632	18,30	1673	17,80	1723		
		19,29	1556	18,79	1633	18,29	1673	17,79	1724		
		19,28	1559	18,78	1634	18,28	1674	17,78	1725		
		19,27	1561	18,77	1635	18,27	1675	17,77	1727		
		19,26	1563	18,76	1636	18,26	1676	17,76	1728		
		19,25	1565	18,75	1637	18,25	1676	17,75	1729		
		19,24	1567	18,74	1638	18,24	1677	17,74	1731		
		19,23	1569	18,73	1639	18,23	1678	17,73	1732		
		19,22	1571	18,72	1640	18,22	1679	17,72	1733		
		19,21	1573	18,71	1641	18,21	1680	17,71	1735		

Powder Batch # : 459

Date : 13/11/2023

Batch approved

 Quality Inspection : 

For inquiries :

Customer Service Desk

Phone : +49 69 27116 432

Fax : +49 69 27116 243

